

**4EMU009** 

## **Change giver NRI G46**



## **Description**

The change giver calculates the remainder of the inserted money and gives back the change.

## **Applicability**

Virtu 40, C-40, 50, C-50, 70, C-70, 90 and C-90 series located in the door. Virtu 10, 20, 30, 60 and 80 series located in a side unit.

Site unit to be ordered separately with article nr. 9MKA001.